


FRONT OF VEHICLE



LIGHTS & REFLECTORS

- o Proper Color (L-R-4-HL-HB-C)
- o Working
- o Not Broken
- o Not cracked
- o Check for puddles
- o Check for drips under engine

ENGINE COMPARTMENT

OIL LEVEL

- o Check for level and condition
- o Check for level and condition
- o Hoses attached and not leaking

POWER STEERING RESERVOIR

- o Mounted properly
- o Hoses attached and not leaking
- o Check for level and condition

WATER PUMP

- o Mounted Securely
- o No missing bolts or parts
- o Hoses attached securely
- o No leaking hoses or water pump
- o Belts no more than ¼ inch of play
- o Belts not cracked or frayed

ALTERNATOR

- o Mounted Securely
- o No missing bolts or parts
- o Wires good connections, not frayed
- o Belt no more than ¼ inch of play
- o Belts not frayed or cracked

AIR COMPRESSOR

- o Mounted Securely
- o No missing bolts or parts
- o No air leaks at lines
- o Check if gear or belt driven
- o Belt no more than ¼ inch of play

- o Belts not cracked or frayed
- o Lines and hoses not leaking

STEERING GEAR BOX

- o Mounted properly

- o No missing parts, nuts or bolts
- o Lines and hoses not leaking or broken

STEERING LINKAGE

- o Pitman arm, Drag link, Steering knuckle, Tie rods and tie rod ends
- o Not cracked, bent or broken
- o Castle nuts and cotter pins
- o Not missing and in place

FRONT WHEEL TIRES (I-C-D)

- o Proper inflation - company or manufacturer specification
- o No bulges, cuts, or retreads
- o Minimum tread depth of 4/32"

RIMS

- o Not bent, cracked, No welding repairs.

LUG NUTS

- o None are missing
- o Tight - no shinny threads, or rust trails

OUTER HUB OIL SEALS

- o Not leaking, no missing bolts
- o Proper oil level

FRONT SUSPENSION

SHOCK ABSORBER

- o Mounted Securely
- o Not bent or dented
- o Not leaking

LEAF SPRINGS

- o Not shifted or out of place
- o Not cracked, broken or missing

SPRING MOUNTS

- o Mounted securely- front, back, and

U-BOLTS

- o Not cracked or broken

FRONT BRAKES

HOSES AND LINES

- o Mounted securely
- o Not leaking
- o Not cracked or frayed

CHAMBER

- o Mounted securely
- o Not dented or damaged
- o Not leaking

SLACK ADJUSTER & PUSH ROD

- o No more than 1 inch of free play at the push rod with the brakes released.
- o Not bent, broken, loose, or missing

DRUMS

- o Not cracked, broken or dented
- o No oil leaking from inner oil seal, free of debris

LININGS

- o No cracked, broken or missing parts
- o Not less than ¼ inch in thickness



DRIVER FUEL AREA

DRIVER'S DOOR

- o Door opens and closes properly
- o Seal is in good condition

DRIVER'S MIRRORS

- o Clean and free of obstruction
- o Not cracked, broken, or damaged

FUEL TANK

- o Mounted securely
- o Not leaking
- o Seal in cap OK

CATWALK

- o Mounted properly
- o Not, missing, or damaged
- o Free of obstructions

LIGHTS & REFLECTORS

- o Clean and working

UNDER VEHICLE

DRIVE SHAFT

- o Not bent, or damaged

- o Coupling, U-joints appear secure

EXHAUST SYSTEM

- o Securely mounted
- o Not dented or damaged
- o Not leaking
- o Not cracked, or damaged
- o No missing bolts
- o No illegal welds

REAR AXLE

TIRES

- o Proper inflation - company or manufacturer specification.
- o No bulges or cuts, can have retreads
- o Minimum tread depth of 2/32"

RIMS

- o Not bent or cracked
- o No welding repairs

LUG NUTS

- o None missing
- o Tight - no shinny threads, or rust trails

OUTER AXLE SEAL

- o Not leaking, no missing bolts

SPACE OR SPACER

- o Check for objects between wheels
- o Check for proper spacing

REAR SUSPENSION

LEAF SPRINGS

- o Not shifted or out of place
- o Not cracked, broken or missing

SPRING MOUNTS

- o Mounted securely - front, back

U-BOLTS

- o Not cracked, or broken
- o Not bent, dented or leaking

AIR BAGS (If Equipped)

- o Mounted Securely
- o Not leaking

REAR BRAKES

HOSES AND LINES

- o Mounted securely

- o Not leaking
- o Not cracked or frayed

CHAMBER

- o Mounted securely
- o Not dented or damaged
- o Not leaking

SLACK ADJUSTER

- o No more than 1 inch of free play at the push rod with the brakes released.
- o No bent, broken, loose, or missing parts

DRUMS

- o Not cracked, broken or dented
- o No oil leaking from inner oil seal, free of debris

LININGS

- o No cracked, broken or missing parts
- o Not less than ¼ inch in thickness

REAR OF VEHICLE

DOORS

- o Not bent, broken, or damaged
- o Close and latch securely
- o Hinges secure, no damage

DOOR TIES

- o Not missing, broken, and securely mounted

SPLASH GUARDS

- o Mounted properly
- o Not missing, ripped or torn

LIGHTS & REFLECTORS

- (L-R-4-TL-BL-C)
- o Working and proper color
- o Not broken, cracked, or missing

This Section to be completed by all drivers

ENGINE START

SAFETY BELT

- o Latches securely
- o Mounted securely

EMERGENCY EQUIPMENT

- o Spare electrical fuses
- o 3 reflective triangles
- o Red ands mounted securely
- o Fire extinguisher